




## Dimensions



## CPU Compartment



When figuring dimensions, include mounted accessories, protruding cables and port replicators or docking stations.



© 2014 Ergotron, Inc. rev. 03/28/2022 DIM-SV41Arm Content is subject to change without notification

### Americas Sales and Corporate Headquarter

St. Paul, MN USA  
(800) 888-8458  
+1-651-681-7600  
www.ergotron.com  
insidesales@ergotron.com

### EMEA Sales

Amersfoort, The Netherlands  
+31 33 45 45 600  
www.ergotron.com  
info.eu@ergotron.com


### APAC Sales

Sydney, Australia  
www.ergotron.com  
apaccustomerservice@ergotron.com


### Worldwide OEM Sales

www.ergotron.com  
info.oem@ergotron.com

## Weight Capacity



## Range of Motion



© 2014 Ergotron, Inc. rev. 03/28/2022 DIM-SV41Arm **Content is subject to change without notification**

### Americas Sales and Corporate Headquarter

St. Paul, MN USA  
 (800) 888-8458  
 +1-651-681-7600  
 www.ergotron.com  
 insidesales@ergotron.com

### EMEA Sales

Amersfoort, The Netherlands  
 +31 33 45 45 600  
 www.ergotron.com  
 info.eu@ergotron.com

### APAC Sales

Sydney, Australia  
 www.ergotron.com  
 apacustomerservice@ergotron.com

### Worldwide OEM Sales

www.ergotron.com  
 info.oem@ergotron.com