










Dell 24 240Hz Monitor SE2426HG




Dell 27 240Hz Monitor SE2726HG



Quick Start Guide






















1





3



2







[Dell.com/support/SE2426HG](https://Dell.com/support/SE2426HG)  
[Dell.com/support/SE2726HG](https://Dell.com/support/SE2726HG)