

2nd fold face out


1st fold face in

2nd fold face out


Front

CKW300

Quick Installation Guide
 Schnellinstallationsanleitung
 Guide d'installation rapide
 Guía de instalación rápida
 Guida all'installazione rapida
 Verkorte installatiegids



1



2



3

Back

Reset • Zurückstellen • Réinitialiser • Reiniciar • Reset • Resetten

ESC + K + P

