



messenger folio™ 2

Online Manual

Warranty Registration


Your ZAGG Messenger Folio™ keyboard and case comes with a one-year manufacturer's warranty. In order to activate the warranty, you must register your Messenger Folio as well as keep your purchase receipt. If you purchased your Messenger Folio from ZAGG.com, ZAGG has already registered it and has a copy of your proof of purchase.

Need more help? Please see our FAQ section at: www.zagg.com/faq



See the important Health and Safety information on page 9 before using this product.

INSERTING/REMOVING YOUR DEVICE



Open the Messenger Folio 2 and lay it flat on your work surface. With your device positioned in landscape mode, slide the top corners of your device into the top two corner clips of the Messenger Folio 2. Then snap the bottom of your device into the bottom centered clip on the Messenger Folio 2. Check the corners of your device to ensure it's snugly in place.

To remove, simply lift the device out of the lower clip and slide your device out.


POWERING ON AND OFF



Open the Messenger Folio 2 and press the Power button located at the top right corner of the keyboard. A green LED will briefly illuminate, indicating the power is on. To turn your Messenger Folio 2 off, press and hold the Power key for three seconds. A red LED will flash, indicating your Messenger Folio has turned off.

PAIRING YOUR MESSENGER FOLIO


Pairing your Messenger Folio 2 is easy. It should only need to be paired once, using the following directions. If the connection between your device and Messenger Folio 2 is ever lost, repeat these steps.



1. Access your device's Bluetooth® settings.
2. Press and hold the Bluetooth® key on the Messenger Folio 2 for three seconds. A blue LED under the Power key will flash until your Messenger Folio 2 and device are paired.
3. Your device will display "ZAGG Keyboard" as an available device. Select this option to complete pairing.

CHARGING YOUR KEYBOARD

Your Messenger Folio 2 features a powerful lithium polymer battery that lasts up to one year between charges*. It comes with a charging cable you can use to charge your keyboard quickly and conveniently. To charge your Messenger Folio 2, follow these steps:




1. Plug the USB connector into the 5V USB charger and plug it into the wall.
2. Plug the Type-C connector into the Messenger Folio 2.
3. A red light under the Power key will illuminate to indicate the Messenger Folio 2 is charging. Wait until this light turns off, indicating a full charge.
4. Remove the USB-C connector and enjoy your Messenger Folio.

**Normal use is approximately one hour of use per day.*

BATTERY LIFE

To check the remaining battery power on your Messenger Folio 2 keyboard, press fn + (battery key). The LED indicator will flash one of three ways:









- 3 green flashes = 50% or more battery life
- 3 yellow flashes = 25-49% battery life
- 3 red flashes = less than 25% battery life

To help preserve battery life, the Messenger Folio 2 will enter sleep mode if left on and not used for several minutes. Press any key to wake it. The Messenger Folio 2's battery has no memory and may be charged whenever you wish.

SPECIAL FUNCTION KEYS

Your Messenger Folio 2 has been designed with the following special function keys to give you more control of your device.

-  **PAIRING** - Activates your device's pairing mode.
-  **HOME** - Displays your device's home screen.
-  **LOCK** - Activates and deactivates your device's sleep mode.
-  **APPS RUNNING** - Displays all of the apps currently running on your device.
-  **LANGUAGE SYMBOL** - Toggles between keyboard language and emojis (if active on your device); pressing cmd + spacebar will do the same.
-  **KEYBOARD HIDE/SHOW** - Hides or shows your onscreen keyboard.
-  **PREVIOUS TRACK** - Skips to the previous track on your selected playlist.
-  **PLAY/PAUSE** - Starts or pauses your currently playlist.
-  **NEXT TRACK** - Skips to the next track on your current playlist.
-  **MUTE** - Mutes your device's audio
-  **VOLUME DOWN** - Decreases your device's volume.
-  **VOLUME UP** - Increases your device's volume.
-  **POWER** - Turns your Pro Keys keyboard on and off.
-  **BATTERY LEVEL** - Indicates remaining battery life.

TROUBLE SHOOTING

If your device does not respond to your Messenger Folio 2, there may be a simple explanation such as a dead battery or an unsuccessful pairing. Please use the following to help troubleshoot your situation. If none of the following solve your issue, then please contact ZAGG Customer Service and one of our trained professionals will be happy to assist you.

1. Restart your device.
2. Turn your Messenger Folio 2 off and back on.
3. Forget and re-pair your Messenger Folio 2.
4. If your Messenger Folio 2 does not establish or maintain a Bluetooth connection, reset the Bluetooth module by charging your keyboard.
5. If, after charging, your keyboard doesn't operate correctly, please contact ZAGG Customer Service.

For more help, please see our FAQ section at www.zagg.com/faq.

To reach a trained customer service representative, please use one of the following:

Zagg.com/support/contact.php | questions@zagg.com

1-800-700-ZAGG [9244] | 00-1-801-839-3906 for international customers

For unparalleled scratch protection for your device, we recommend InvisibleShield® screen protection.



Please read the precautions and operation information before using your keyboard or any accessories that accompany it. Retain this information for future use.

1. Take frequent breaks when using your keyboard. If you experience any discomfort, pain, tingling, numbness, or burning in your neck, shoulders, arms, wrists, hands, or any other part of the body, stop using your keyboard and consult a physician.
2. Use only Type-C USB chargers in connection with your keyboard.
3. Do not attempt to service your keyboard.
4. Do not disassemble or attempt to disassemble your keyboard.
5. Do not crush or puncture your keyboard.
6. Do not immerse your keyboard in water.
7. Do not put your keyboard in contact with water or other liquids as they could cause a short circuit, fire, or electric shock that could result in injury, death, or property damage.
8. Do not use liquid or aerosol cleaners or solvents on or near your keyboard. Clean only with a soft, dry cloth. Disconnect any cords before cleaning the keyboard.
9. Do not use your keyboard while operating a motorized vehicle, including automobile, boat, or airplane. Doing so could put you and others at risk of serious injury, death, or property damage.
10. Do not use or place your keyboard near any heat sources including, but not limited to, radiators, heat registers, stoves, other appliances, campfires, or barbecue grills.
11. To reduce the risk of fire or electric shock, wire or connect your keyboard to products only in the manner instructed in the documentation included herewith. Do not attempt to modify or adjust any ports. Any improper connections or adjustments may cause damage.
12. When you are ready to discard your keyboard, recycle your keyboard in a manner consistent with electronic recycling requirements or recommendations in your geographic area.

©2020 ZAGG Inc All Rights Reserved

PATENTS: zaggs.com/patents | NASDAQ: ZAGG | MADE IN CHINA

Apple and iPad Pro are trademarks of Apple Inc., registered in the U.S. and other countries. The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by ZAGG Inc is under license. USB-C is a trademark of USB Implementers Forum. Other trademarks and trade names are those of their respective owners. ZAGG, InvisibleShield, and Messenger Folio are trademarks of ZAGG Inc.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FEDERAL COMMUNICATION COMMISSION INTERFERENCE STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC CAUTION

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. The product complies and is safe with the FCC portable RF exposure limit set forth for an uncontrolled environment and are safe for intended operation as described in this manual. The further RF exposure reduction can be achieved if the product can be kept as far as possible from the user body or set the device to lower output power if such function is available.