


# BE249QG Series LCD Monitor

# **User Guide**





# Table of contents

| ertified. |  | III  |
|-----------|--|--|
| s         |  | iv   |
| informa   | ation  | vi   |
| Cleani    | ng   | ix   |
| Welco     | me!  | 1-1  |
| Packag    | ge contents  | 1-1  |
| Assem     | nbling the monitor   | 1-2  |
| Conne     | ect cables   | 1-3  |
| 1.4.1     |  |  |
| 1.4.2     | Six sides figure   | 1-4  |
| Monito    | or introduction  | 1-5  |
| 1.5.1     | Using the Controls button  | 1-5  |
| 1.5.2     | Function of Stand/Base   | 1-7  |
| Detach    | ning the arm/stand (for VESA wall mount)   | 2-1  |
| Installi  | ing the Mini PC Kit  | 2-2  |
| Adjust    | ting the monitor   | 2-3  |
| OSD (     | On-Screen Display) menu  | 3-1  |
| •         |  |  |
| 3.1.2     | OSD Function Introduction  | 3-2  |
| Specif    | ications   | 3-11   |
| Troubl    | leshooting (FAQ)   | 3-13   |
| Suppo     | orted Timing List  | 3-14   |
|           | informa Cleania Welco Packa Assen Conne 1.4.1 1.5.2 Monito 1.5.2 Detacl Install Adjust OSD (0 3.1.1 3.1.2 Specif Troub | information Cleaning Welcome! Package contents Assembling the monitor Connect cables 1.4.1 Rear of the LCD monitor 1.4.2 Six sides figure Monitor introduction 1.5.1 Using the Controls button 1.5.2 Function of Stand/Base Detaching the arm/stand (for VESA wall mount) Installing the Mini PC Kit Adjusting the monitor  OSD (On-Screen Display) menu 3.1.1 How to reconfigure 3.1.2 OSD Function Introduction Specifications Troubleshooting (FAQ) Supported Timing List |

Copyright © 2025 ASUSTeK COMPUTER INC. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUSTEK COMPUTER INC. ("ASUS").

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

# **TCO Certified**

A third-party certification according to ISO 14024





# Say hello to a more sustainable product

IT products are associated with a wide range of sustainability risks throughout their life cycle. Human rights violations are common in the factories. Harmful substances are used both in products and their manufacture. Products can often have a short lifespan because of poor ergonomics, low quality and when they are not able to be repaired or upgraded.

This product is a better choice. It meets all the criteria in TCO Certified, the world's most comprehensive sustainability certification for IT products. Thank you for making a responsible product choice, that help drive progress towards a more sustainable future!

Criteria in TCO Certified have a life-cycle perspective and balance environmental and social responsibility. Conformity is verified by independent and approved verifiers that specialize in IT products, social responsibility or other sustainability issues. Verification is done both before and after the certificate is issued, covering the entire validity period. The process also includes ensuring that corrective actions are implemented in all cases of factory non-conformities. And last but not least, to make sure that the certification and independent verification is accurate, both TCO Certified and the verifiers are reviewed regularly.

### Want to know more?

Read information about TCO Certified, full criteria documents, news and updates at **tcocertified.com**. On the website you'll also find our Product Finder, which presents a complete, searchable listing of certified products.

# **Notices**

### **Federal Communications Commission Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- · This device may not cause harmful interference, and
- This device must accept any interference received including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# **Canadian Department of Communications Statement**

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

This class B digital apparatus complies with Canadian ICES-003.



# **Declaration of Conformity**

This device complies with the requirements set out in the Council Directive on the Approximation of the Laws of the Member States relating to Electromagnetic Compatibility (2014/30/EU), Low-voltage Directive (2014/35/EU), REGULATION (EU) 2024/1781 and RoHS directive (2011/65/EU). This product has been tested and found to comply with the harmonized standards for Information Technology Equipment, these harmonized standards published under Directives of Official Journal of the European Union.

### **WEEE Symbol Statement**

This symbol on the product or on its packaging indicates that this product must not be disposed of with your other household waste. Instead, it is your responsibility to dispose of your waste equipment by handing it over to a designated collection point for the recycling of waste electrical and electronic equipment. The separate collection and recycling of your waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the shop where you purchased the product.



| ı   | ■ ASUS CONTACT INFORMATION      |  |   |                 |  |   |                 |  |
|---|---------------------------------|--|---|-----------------|--|---|-----------------|--|
| <ul> <li>ASUSTeK Computer Inc.</li> </ul> |                                 |  |   | ASUS Computer   | International (America)                  | • | ASUS Computer   | GmbH (Germany and Austria)                     |
|   | Address                         | 1F, No. 15,<br>Lide Rd., Beitou Dist., |   | Address         | 48720 Kato Rd, Fremont,<br>CA 94538, USA |   | Address         | Harkortstr. 21-23<br>D-40880 Ratingen, Germany |
|   |                                 | Taipei City 112, Taiwan                |   | Telephone       | +1-510-739-3777                          |   | Telephone       | +49-1805-010920                                |
|   | Telephone                       | +886-2-2894-3447                       |   | Fax<br>Website  | +1-510-608-4555                          |   | Website         | http://www.asus.de/                            |
|   | Fax                             | +886-2-2894-7798                       |   | vvebsite        | http://usa.asus.com/                     |   | Online Contact  | http://www.asus.de/sales                       |
|   | E-mail                          | info@asus.com.tw                       |   |                 |  |   |                 |  |
|   | Website                         | http://www.asus.com.tw/                |   |                 |  |   |                 |  |
|   |                                 |  | • | Technical Suppo | ort                                      |   | Technical Suppo | ort  |
|   | <ul> <li>Technical S</li> </ul> | upport                                 |   | Telephone       | +1-812-282-2787 (English Only)           |   | Telephone       | +49-1805-010923                                |
|   | Telephone                       | +86-21-38429911                        |   |                 | +1-905-370-2787 (French Only)            |   | Support Fax     | +49-2102-959911                                |
|   | ·                               |  |   | Online Support  | http://support.asus.com/                 |   | Online Support  | http://support.asus.com/                       |

# Safety information

- Before setting up the monitor, carefully read all the documentation that came with the package.
- To prevent fire or shock hazard, never expose the monitor to rain or moisture.
- Never try to open the monitor cabinet. The dangerous high voltages inside the monitor may result in serious physical injury.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.
- Before using the product, make sure all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- Slots and openings on the back or top of the cabinet are provided for ventilation. Do not block these slots. Never place this product near or over a radiator or heat source unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supply to your home, consult your dealer or local power company.
- Use the appropriate power plug which complies with your local power standard.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- Avoid dust, humidity, and temperature extremes. Do not place the monitor in any area where it may become wet. Place the monitor on a stable surface.
- Unplug the unit during a lightning storm or if it will not be used for a long period of time. This will protect the monitor from damage due to power surges.
- Never push objects or spill liquid of any kind into the slots on the monitor cabinet.
- To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100 ~ 240V AC.
- The socket-outlet shall be installed near the equipment and shall be easily accessible
- If you encounter technical problems with the monitor, contact a qualified servic er.
- Provide an earthing connection before the mains plug is connected to the mains. And, when disconnecting the earthing connection, be sure to disconnect after pulling out the mains plug from the mains.

### WARNING

Usage of other than specified head- or earphones can result in hearing loss due to excessive sound pressures.

Please confirm the distribution system in building installation shall provide the circuit breaker rated 120/240V, 20A (maximum).

If provided with a 3-pin attachment plug on the power cord, plug the cord into a grounded (earthed) 3-pin outlet. Do not disable the power cord grounding pin, for example, by attaching a 2-pin adapter. The grounding pin is an important safety feature.

To avoid electrical shock, always use the power cord and plug with a properly grounded power outlet.

Stability Hazard.

The product may fall, causing serious personal injury or death. To prevent injury, this product must be securely attached to the floor/wall in accordance with the installation instructions.

A product may fall, causing serious personal injury or death. Many injuries, particularly to children, can be avoided by taking simple precautions such as:

ALWAYS use cabinets or stands or installation methods recommended by the manufacturer of the product set.

ALWAYS use furniture that can safely support the product.

ALWAYS ensure the product is not overhanging the edge of the supporting furniture.

ALWAYS educate children about the dangers of climbing on furniture to reach the product or its controls.

ALWAYS route cords and cables connected to your product so they cannot be tripped over, pulled or grabbed.

NEVER place a product in an unstable location.

NEVER place the product on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the product to a suitable support.

NEVER place the product on cloth or other materials that may be located between the product and supporting furniture.

NEVER place items that might tempt children to climb, such as toys and remote controls, on the top of the product or furniture on which the product is placed.

If the existing product is going to be retained and relocated, the same considerations as above should be applied.

Excessive sound pressure from earphones and headphones can cause hearing loss. Adjustment of the equalizer to maximum increases the earphones and headphones output voltage and therefore the sound pressure level.

Restriction on Hazardous Substances statement (India) This product complies with the "India E-Waste (Management) Rules, 2016" and prohibits use of Lead, Mercury, Hexavalent Chromium, polybrominated biphenyls(PBBs) and polybrominated diphenyl ethers(PBDEs) in concentration exceeding 0.1% by weight in homogenous materials and 0.01% by weight in homogenous materials for cadmium, except of exemptions listed in Schedule 2 of the Rule.

# **Care & Cleaning**

- Before you lift or reposition your monitor, it is better to disconnect the cables and power cord. Follow the correct lifting techniques when positioning the monitor. When lifting or carrying the monitor, grasp the edges of the monitor. Do not lift the display by the stand or the cord.
- Cleaning. Turn your monitor off and unplug the power cord. Clean the monitor surface with a lint-free, non-abrasive cloth. Stubborn stains may be removed with a cloth dampened with mild cleaner.
- Avoid using a cleaner containing alcohol or acetone. Use a cleaner intended for use with the LCD. Never spray cleaner directly on the screen, as it may drip inside the monitor and cause an electric shock.

### The following symptoms are normal with the monitor:

- The screen may flicker during the initial use due to the nature of the fluorescent light. Turn off the Power Switch and turn it on again to make sure that the flicker disappears.
- You may find slightly uneven brightness on the screen depending on the desktop pattern you use.
- When the same image is displayed for hours, an afterimage of the previous screen may remain after switching the image. The screen will recover slowly or you can turn off the Power Switch for hours.
- When the screen becomes black or flashes, or cannot work anymore, contact your dealer or service center to fix it. Do not repair the screen by yourself!

# Conventions used in this guide



WARNING: Information to prevent injury to yourself when trying to complete a task.



CAUTION: Information to prevent damage to the components when trying to complete a task.



IMPORTANT: Information that you MUST follow to complete a task.



NOTE: Tips and additional information to aid in completing a task.

### Where to find more information

Refer to the following sources for additional information and for product and software updates.

### 1. ASUS websites

The ASUS websites worldwide provide updated information on ASUS hardware and software products. Refer to http://www.asus.com

### 2. Optional documentation

Your product package may include optional documentation that may have been added by your dealer. These documents are not part of the standard package.

### 3. Protect your eyes with ASUS EYE CARE Monitors

The latest ASUS monitors feature exclusive Blue Lighe Filter and Flicker free technologies to keep your eyes healthy in today's digital world. Refer to

https://www.asus.com/Microsite/display/eye\_care\_technology/

### **Takeback Services**

ASUS recycling and takeback programs come from our commitment to the highest standards for protecting our environment. We believe in providing solutions for our customers to be able to responsibly recycle our products, batteries and other components as well as the packaging materials. Please go to http://csr.asus.com/english/Takeback.htm for detail recycling information in different region.

# Product information for EU energy label



### 1.1 Welcome!

Thank you for purchasing the ASUS® LCD monitor!

The latest widescreen LCD monitor from ASUS provides a crisper, broader, and brighter display, plus a host of features that enhance your viewing experience.

With these features, you can enjoy the convenience and delightful visual experience that the monitor brings you!

# 1.2 Package contents

Check your package for the following items:

- ✓ LCD Monitor
- ✓ Monitor Stand
- ✓ Monitor Base
- ✓ Monitor VESA Cover
- ✓ Quick Start Guide
- ✓ Warranty Card
- ✓ Power Cord \*
- ✓ HDMI Cable \*
- ✓ USB 3.2 Cable \*
- ✓ Mini PC Kit (Optional)
- ✓ Phone holder stickers




- If any of the above items is damaged or missing, contact your retailer immediately.
- \* Also the Replaceable parts required by the TCO Certified.

# 1.3 Assembling the monitor

# To assemble the monitor:


- Place the display on a cloth on the table, Then attach the base to the arm and fix with the screw to join them tightly. You can easily tighten the screw by fingers.
- 2. Adjust the monitor to the angle that is most comfortable for you.



<sup>\*</sup>Base screw size: M6 x 20mm

# 1.4 Connect cables


# 1.4.1 Rear of the LCD monitor



- 1. AC-IN Port
- 2. DP In Port
- 3. HDMI Port
- 4. VGA Port
- 5. Line In
- 6. Earphone Out
- 7. USB3.2 Gen1 Type-B Port
- 8. USB3.2 Gen1 Type-A Port
- 9. USB3.2 Gen1 Type-A Port
- 10. USB3.2 Gen1 Type-A Port
- 11. Kensington Lock

# 1.4.2 Six sides figure


BE249QG UNIT:mm [inch]



# 1.5 Monitor introduction

# 1.5.1 Using the Controls button

Use the control button on the front of the monitor to adjust the image settings.



### 1. Power Indicator:

• The color definition of the power indicator is as the below table.

| Status | Description  |  |  |  |
|--------|--------------|--|--|--|
| White  | ON           |  |  |  |
| Amber  | Standby mode |  |  |  |
| OFF    | OFF          |  |  |  |

# 2. U Power Button:

Press this button to turn the monitor on/off.

# 3. Bhortcut Key3:

- Press this button to display the OSD menu when the OSD is off.
- Default: Quickfit hotkey.
- To change the hotkey function, go to the Shortcut > Shortcut 3 menu.

# 4. Shortcut Key2:

- · Press this button to display the OSD menu when the OSD is off.
- Default: Brightness hotkey.
- To change the hotkey function, go to the Shortcut > Shortcut 2 menu.

### 

- Press this button to display the OSD menu when the OSD is off.
- Default: Energy Saving hotkey.
- To change the hotkey function, go to the Shortcut > Shortcut 1 menu.

### 

- · Press this button to display the OSD menu when the OSD is off.
- · Input shortcut key.

# 7. X Exit Button:


- Press this button to display the OSD menu when the OSD is off.
- · Exit the OSD menu.

# 8. : (5-way) Button:

- · Press this button to display the OSD menu when the OSD is off.
- Turn on the OSD menu. Enact the selected OSD menu item.
- Increase/Decrease values or moves your selection up/down/left/ right.

1-6 Chapter 2: Setup

# 1.5.2 Function of Stand/Base



### 1. Cable management

You can organize the cables with the help of the cable management slot.

### 2. Phone holder:

- The size of the phone holder is 13 x 228.6 mm. Make sure your device fits into the groove.
- You can paste the phone holder stickers on the inside of the front side ofthe groove to protect your device.

# 2.1 Detaching the arm/stand (for VESA wall mount)


The detachable stand of this monitor is specially designed for VESA wall mount.

### To detach the arm/stand

- Disconnect power and signal cables. Carefully put the front of the monitor face down on a clean table.
- Press the release button to detach the stand (arm and base) from the monitor.



 We recommend that you cover the table surface with soft cloth to prevent damage to the monitor.




\*Vesa mount: 100 x 100mm
\*Screw size: M4 x 8mm

# 2.2 Installing the Mini PC Kit

The installation method is as follows:


- Fixed the base with your hand and lift the cable holder upwards (Figure 1).
- 2. Remove the cable holder (Figure 2).
- 3. Install the Mini PC Kit to the Column with hook (Figure 3).
- 4. Put the Mini PC Kit down to lock them up (Figure 4).



2-2 Chapter 2: Setup


# 2.3 Adjusting the monitor

- For optimal viewing, we recommend that you look at the full face of the monitor, then adjust the monitor to the angle that is most comfortable for you.
- Hold the stand to prevent the monitor from falling when you change its angle.
- You can adjust the monitor's angle from +35° to -5° and You can also adjust the monitor's height within 150 mm. Before rotating the display, lift it to the top position and then push it back to the utmost degree.
   Rotate clockwise or counter-clockwise until the monitor stops at ±90°.



# 3.1 OSD (On-Screen Display) menu

# 3.1.1 How to reconfigure




- 1. Press the MENU button to activate the OSD menu.
- Press the ▼ and ▲ buttons to toggle between options in the Menu. As you move from one icon to another, the option name is highlighted.
- 3. To select the highlighted item on the menu press the Central key.
- 4. Press the ▼ and ▲ buttons to select the desired parameter.

### 3.1.2 OSD Function Introduction

### 1. Splendid

This function contains eight sub-functions that you can select for your preference.



- Standard Mode: This is the best choice for document editing with SPLENDID™ Video Intelligence Technology.
- sRGB Mode: This is the best choice for viewing photos and graphics from PCs.
- Scenery Mode: This is the best choice for scenery photo displaying with SPLENDID™ Video Intelligence Technology.
- Theater Mode: This is the best choice for movie watching with SPLENDID™ Video Intelligence Technology.
- Game Mode: This is the best choice for game playing with SPLENDID™ Video Intelligence Technology.
- Night View Mode: This is the best choice for playing dark-scene game or watching dark-scene movie with SPLENDID™ Video Intelligence Technology.
- Reading Mode: This is the best choice for book reading.
- Darkroom Mode: This is the best choice for a weak ambient light environment.



- In the Standard Mode, the Saturation, ASCR functions are not userconfigurable.
- In the sRGB, the Saturation, Color Temp., Contrast and ASCR functions are not user-configurable.
- In the Reading Mode, the Saturation, ASCR, contrast, and Color Temp functions are not user-configurable.

### 2. EveCare

Adjust the energy level of Eye Care from LED backlight.



Blue Light Filter: In this function, you can adjust the blue light filter from
0 to max. 0: no changes; Max: The higher the level, the less blue light
is scattered. When blue light filter is activated, the default settings of
Standard Mode will be automatically imported. Besides maximum level,
the brightness is user-configurable. Maximum is the optimized setting.
It is compliance with TUV low blue light certification\*. The brightness
function is not user configurable.



- When the user adjusts blue light filter bar to maximum level.
- \*When color augmentation is in default value (50).
- Rest Reminder: This function provides you a rest reminder according
  to how long you set for your working time. For example, a user sets 30
  minutes working time and there will be a pop up reminder appeared on
  the upper left corner of the monitor for 5 seconds. Press any key to make
  this reminder OSD disappeared.



- When this function is enable, the following functions are not available:
   GamePlus and QuickFit
- Color Augmentation: The adjusting range of color enhancement is from 0 to 100.



This function is not available in sRGB mode under Splendid.



Please refer to the following to alleviate eye strains:

- Users should take some time away from the display if working for long hours.
  It is advised to take short breaks (at least 5 mins) after around 1 hour of
  continuous working at the computer. Taking short and frequent breaks is more
  effective than a single longer break.
- To minimize eye strain and dryness in your eyes, users should rest the eye
  periodically by focusing on objects that are far away.
- Eye exercises can help to reduces eye strain. Repeat these exercises often. If
  eye strain continues please consult a physician. Eye exercises: (1) Repeating
  look up and down (2) Slowly roll your eyes (3) Move your eyes diagonal.
- High energy blue light may lead to eye strain and AMD (Age-Related Macular Degeneration). Blue light filter to reduce 70% (max.) harmful blue light to avoiding CVS (Computer Vision Syndrome).

### 3. Color

Select the image color you like from this function.



- Brightness: The adjusting range is from 0 to 100.
- Contrast: The adjusting range is from 0 to 100.
- Saturation: The adjusting range is from 0 to 100.
- Color Temp.: Contains three preset color modes (Cool, Normal, Warm) and User Mode.



 In the User Mode, colors of R (Red), G (Green), and B (Blue) are userconfigurable; the adjusting range is from 0 ~ 100.

### 4. Image

You can adjust the image Sharpness, Trace Free, Aspect Control, ASCR, VGA Adjust, Adaptive-Sync, HDR from this main function.



- Sharpness: Adjusts the picture sharpness. The adjusting range is from 0 to 100.
- Trace Free: Speeds up the response time by Over Drive technology. The adjusting range is from lower 0 to faster 100.
- Aspect Control: Adjusts the aspect ratio to "Full", "1:1 Ratio".
- ASCR: Select ON or OFF to enable or disable dynamic contrast ratio function.
- VGA Adjust: Adjusts the horizontal position (H Position) and the vertical position (V Position) of the image.Reduces Horizonal-line noise and Vertical-line noise of the image by adjusting (Focus Phase) and (Focus Clock) separately.Or automatically adjust the image to its optimized position, clock, and phase.
- Adaptive-Sync: It can allow a Adaptive-Sync supported graphics source to dynamically adjust display refresh rate based on typical content frame rates for power efficient, virtually stutter free and low-latency display update.
- HDR: Set the HDR mode to Gaming or Cinema.

### 5. Input

Select the input source: VGA, HDMI, DisplayPort and Auto Detection.



### 6. Settings

Adjusts the system configuration.



- **Sound**: Adjust the sound settings to your preference.
- QuickFit: contains two patterns: (1) Paper size (2) Photo size.
  - Paper size: Provides users to view their documents in real size on the screen.





Photo size: Provides photographers and other users to accurately view and edit their photos in real size on the screen.



- Dynamic Dimming: Dynamic local dimming, turn on this feature to improve the dynamic contrast.
- Power Saving: Adjusts the "Normal Level" and "Deep Level" for the Power Saving function.
- DisplayPort Stream: Select DisplayPort 1.2 if your graphics card is not compatible with DisplayPort 1.4.
- OSD Setup: Adjusts the OSD Timeout, DDC/CI, and Transparency of the OSD screen.
- Language: Select OSD language. The selections are: English, French, German, Spanish, Italian, Dutch, Russian, Poland, Czech, Croacia, Hungary, Romania, Portugal, Turkey, Simplified Chinese, Traditional Chinese, Japanese, Korean, Persian, Thai, Indonesian, Ukraine, and Vietnamese.

ASUS Power Sync: Enables or disables the ASUS Power Sync function.
 To activate this function, please enable this function of the monitor via HDMI port.



 When Auto Detection is enabled, the monitor won't switch to DC OFF once the source device is turned off.



Please take a look at the ASUS website to check which devices are compatible with this function.

To enable monitor to turn on and off the hardware or vise versa, please set up your computer BIOS by the following.

BIOS set up instruction for ASUS NUC:



BIOS set up instruction for ASUS Mini PC:



- Key Lock: Disable all key functions. Pressing the down button for more than five seconds to disable key lock function.
- **Information:** Displays the monitor information.
- Power Indicator: Turn the power LED indicator on/off.
- Power Key Lock: To disable / enable power key.
- All Reset: Selects "Yes" to revert all settings to the factory default mode.

### 7. Shortcut

Selecting this option allows you to set three shortcut keys.



- Shortcut 1: User can select from "Blue Light Filter"
   "Splendid", "Brightness", "Auto Adjust", "Contrast", "Input",
   "Color Temp.", "Volume", "QuickFit", "Rest Reminder", "Color Augmentation", "Energy Saving" and set as shortcut key. The default setting is Energy Saving.
- Shortcut 2: User can select from "Blue Light Filter" "Splendid", "Brightness", "Auto Adjust", "Contrast", "Input", "Color Temp.", "Volume", "QuickFit", "Rest Reminder", "Color Augmentation", "Energy Saving" and set as shortcut key. The default setting is Brightness.
- Shortcut 3: User can select from "Blue Light Filter"
   "Splendid", "Brightness", "Auto Adjust", "Contrast", "Input",
   "Color Temp.", "Volume", "QuickFit", "Rest Reminder", "Color
   Augmentation", "Energy Saving" and set as shortcut key. The
   default setting is Quickfit.

# 3.2 Specifications

| Model                         | BE249QG  |  |  |  |
|-------------------------------|--|--|--|--|
| Panel Size                    | 23.8"W   |  |  |  |
| Max. Resolution               | 1920x1080@120Hz                                    |  |  |  |
| Brightness (Typ.)             | 350cd/m <sup>2</sup>                               |  |  |  |
| Contrast ratio (typical)      | 1500 : 1<br>178°(V) /178°(H)                       |  |  |  |
| Viewing Angle (CR>10)         |  |  |  |  |
| Display Colors                | 16.7M (RGB 6bits + HFRC)                           |  |  |  |
| Response Time                 | 5ms (Gray to Gray)                                 |  |  |  |
| Earphone Output               | Yes  |  |  |  |
| Sound from HDMI/DP            | Yes  |  |  |  |
| Input                         | Displayport v1.2 x1, HDMI v1.4 x1, VGA x1          |  |  |  |
| USB3.2 Gen1 Type-B            | Yes  |  |  |  |
| USB Port                      | 5V/0.9A (Downstream x3)<br>5V/1.5A (Downstream x1) |  |  |  |
| Voltage Rating                | 100~240V, 50/60Hz, 1.5A                            |  |  |  |
| Power On<br>Consumption (max) | 9.86W**  |  |  |  |
| Power saving mode             | < 0.5W   |  |  |  |
| Power off mode                | 0W (AC Switch Off)                                 |  |  |  |
| Colors                        | Black  |  |  |  |
| Tilt                          | -5° ~ +35°   |  |  |  |
| Pivot                         | +90°~ -90°   |  |  |  |
| Swivel                        | +180°~ -180°                                       |  |  |  |
| Height Adjustment             | 150mm  |  |  |  |
| Kensington lock               | Yes  |  |  |  |
| VESA Wall Mounting            | Yes (100mm x 100mm)                                |  |  |  |

| Phys. Dimension with stand (WxHxD)                          | 540.15mm x 507.46mm x 224.00mm |  |  |
|---|--------------------------------|--|--|
| Phys. Dimension without stand (WxHxD) (For VESA Wall Mount) | 540.15mm x 323.79mm x 49.61mm  |  |  |
| Box Dimension (WxHxD)                                       | 690mm x 445mm x 139mm          |  |  |
| Net Weight (Esti.)  | 5.36 kg                        |  |  |
| Net Weight (Esti. w/o stand)                                | 3.25 kg                        |  |  |
| Gross Weight (Esti.)  | 8.05 kg                        |  |  |
| Temperature (Operating)                                     | 0°C~ 40°C                      |  |  |
| Operating Humidity  | 10% ~ 80%                      |  |  |
| Altitude  | 16,404 feet( 5,000m)           |  |  |

<sup>\*</sup> Specifications are subject to change without notice.
\*\* Measuring a screen brightness of 200 nits without audio/USB/Card reader connection

# 3.3 Troubleshooting (FAQ)

| Problem  | Possible Solution   |  |  |  |
|--|---|--|--|--|
| Power LED is not ON  | <ul> <li>Press the O button to check if the monitor is in the ON mode.</li> <li>Check if the power cord is properly connected to the monitor and the power outlet.</li> <li>Check Power Indicator function in main menu OSD. And turn on this function to turn on the power LED light.</li> </ul>   |  |  |  |
| The power LED lights amber and there is no screen image        | <ul> <li>Check if the monitor and the computer are in the ON mode.</li> <li>Make sure the signal cable is properly connected the monitor and the computer.</li> <li>Inspect the signal cable and make sure none of the pins are bent.</li> <li>Connect the computer with another available monitor to check if the computer is properly working.</li> </ul> |  |  |  |
| Screen image is too light or dark                              | Adjust the Contrast and Brightness settings via OSD.  |  |  |  |
| Screen image bounces or a wave pattern is present in the image | <ul> <li>Make sure the signal cable is properly connected to<br/>the monitor and the computer.</li> <li>Move electrical devices that may cause electrical<br/>interference.</li> </ul>  |  |  |  |
| Screen image has color defects<br>(white does not look white)  | <ul> <li>Inspect the signal cable and make sure that none of the pins are bent.</li> <li>Perform Reset via OSD.</li> <li>Adjust the R/G/B color settings or select the Color Temperature via OSD.</li> </ul>  |  |  |  |
| No sound or sound is low                                       | <ul> <li>Make sure the audio cable is properly connected to the monitor.</li> <li>Adjust the volume settings of both your monitor and computer.</li> <li>Make sure the computer sound card driver is properly installed and activated</li> </ul>  |  |  |  |

# 3.4 Supported Timing List

# **Support Timing**

| Timing        | Resolution            | HDMI 1.4 | DP 1.2 | VGA |
|---------------|-----------------------|----------|--------|-----|
| PC Timing     | 640x480-60Hz          | V        | V      | V   |
| PC Timing     | 640x480-75Hz          | V        | V      | V   |
| PC Timing     | 800x600-60Hz          | V        | V      | V   |
| PC Timing     | 800x600-75Hz          | V        | V      | V   |
| PC Timing     | 1024x768-60Hz         | V        | V      | V   |
| PC Timing     | 1024x768-75Hz         | V        | V      | V   |
| PC Timing     | 1280x960-60Hz         | V        | V      | V   |
| PC Timing     | 1280x1024-60Hz        | V        | V      | V   |
| PC Timing     | 1280x720-60Hz         | V        | V      | V   |
| PC Timing     | 1600x900-60Hz         | V        | V      | V   |
| PC Timing     | 1920x1080-60Hz        | V        | V      | V   |
| Video Timing  | 640x480P-60Hz         | V        | V      |     |
| Video Timing  | 720x480P-60Hz         | V        | V      |     |
| Video Timing  | 720x576P-50Hz         | V        | V      |     |
| Video Timing  | 1280x720P-50Hz        | V        | V      |     |
| Video Timing  | 1280x720P-60Hz        | V        | V      |     |
| Video Timing  | 1920x1080P-23.98/24Hz | V        | V      |     |
| Video Timing  | 1920x1080P-25Hz       | V        | V      |     |
| Video Timing  | 1920x1080P-30Hz       | V        | V      |     |
| Video Timing  | 1920x1080P-50Hz       | V        | V      |     |
| Video Timing  | 1920x1080P-60Hz       | V        | V      |     |
| Video Timing  | 1920x1080P-120Hz      | V        | V      |     |
| Video Timing  | 1920x1080P-100Hz      | V        | V      |     |
| Detail Timing | 1920x1080-120Hz       | V        | V      |     |
| Detail Timing | 1920x1080-100Hz       | V        | V      |     |
| Detail Timing | 1920x1080-75Hz        | V        | V      | V   |
| Detail Timing | 1920x1080-60Hz        | V        | V      | V   |

<sup>\*</sup> The modes not listed in the above tables may not be supported. For optimal resolution, we recommend that you choose a mode listed in the above tables.