

MAG Series

LCD Monitor

MAG 322URDF E16 (3DD8)

User Guide

Contents

Getting Started	3
Package Contents	3
Installing the Monitor Stand	4
Adjusting the Monitor	5
Monitor Overview	6
Connecting the Monitor to PC	9
OSD Setup	10
Navi Key	10
Hot Key	10
OSD Menus	11
G.I	12
Gaming	13
Professional	15
Image	16
Input Source	16
PIP/PBP	17
Navi Key	18
Settings	18
Specifications	20
Preset Display Modes	22
Troubleshooting	25
Safety Instructions	26
TÜV Rheinland Certification	
Regulatory Notices.	29

Revision

V1.0, 2025/07

Getting Started

This chapter provides you with the information on hardware setup procedures. While connecting devices, be careful in holding the devices and use a grounded wrist strap to avoid static electricity.

Package Contents

Monitor	MAG 322URDF E16	
Documentation	Quick Start Guide	
Accessories	Stand with Screw(s)	
	Stand Base with Screw(s)	
	Power Cord	
DisplayPort Cable (Optional)		
Cables	USB Upstream Cable (Optional)	
	(for USB Type-B Upstream Port)	




/ Important

- Contact your place of purchase or local distributor if any of the items is damaged or missing.
- Package contents may vary by country and model.
- The included power cord is exclusively for this monitor and should not be used with other products.

Installing the Monitor Stand

- 1. Leave the monitor in its protective packaging. Align the stand bracket to the monitor groove.
- 2. Tighten the stand bracket with screws.
- 3. Connect the base to the stand and tighten the base screw to secure the base.
- 4. Make sure the stand assembly is properly installed before setting the monitor upright.



Important

- Place the monitor on a soft, protected surface to avoid scratching the display panel.
- Do not use any sharp objects on the panel.
- The groove for installing the stand bracket can also be used for wall mount. Please contact your dealer for proper wall mount kit.
- This product comes with NO protective film to be removed by the user! Any
 mechanical damages to the product including removal of the polarizing film may
 affect the warranty!




Adjusting the Monitor

This monitor is designed to maximize your viewing comfort with its adjustment capabilities.



Important

Avoid touching the display panel when adjusting the monitor.










Monitor Overview



- 1 Cable Routing Hole
- Power LED

 Lit in white after the monitor is turned on. If no signal input, the LED will turn into orange. Lit in orange when the monitor is in Stand-by mode.
- 3 Navi Key
- 4 Power Button
- 5 Power Jack
- 6 Kensington Lock
- HDMI™ Connector HDMI™

Supports HDMI[™] CEC, 3840x2160@160Hz as specified in HDMI[™] 2.1.



Important

To ensure optimal performance and compatibility, please use only HDMI™ cables certified with the official HDMI™ logo when connecting this monitor. For more information, please visit https://www.hdmi.org/resource/cables.

8 HDMI™ Connector HDMI™

Supports 3840x2160@160Hz as specified in HDMI™ 2.1.



Important


To ensure optimal performance and compatibility, please use only $HDMI^{TM}$ cables certified with the official $HDMI^{TM}$ logo when connecting this monitor. For more information, please visit $\frac{https://www.hdmi.org/resource/cables}{https://www.hdmi.org/resource/cables}$.

- **9** DisplayPort Supports UHD 3840x2160@160Hz as specified in DisplayPort 1.4a.
- USB 2.0 Type-B Upstream Port
 For USB Upstream Cable.



! Important


Check the package for USB Upstream Cable and connect it to the PC and monitor. Once this cable is connected, the USB Type-A Downstream Ports on the monitor will be ready for use.



1	USB 2.0 Type-A Port
Ð	Headphone Jack

Connecting the Monitor to PC

- 1. Turn off your computer.
- 2. Connect the video cable from the monitor to your computer.
- 3. Connect the power cord to the monitor power jack. (Figure A)
- 4. Plug the power cord into the electrical outlet. (Figure B)
- 5. Turn on the monitor. (Figure C)
- 6. Power on the computer and the monitor will auto detect the signal source.



OSD Setup

This chapter provides you with essential information on OSD Setup.




) Important

All information is subject to change without prior notice.

Navi Key

The monitor comes with a Navi Key, a multi-directional control that helps navigate the On-Screen Display (OSD) menu.



Up/Down/Left/Right:

- selecting function menus and items
- adjusting function values
- entering into/exiting from function menus


Press (OK):

- launching the On-Screen Display (OSD)
- · entering submenus
- confirming a selection or setting

Hot Key

- Users may enter into preset function menus by moving the Navi Key up, down, left or right when the OSD menu is inactive.
- Users may customize their own Hot Keys to enter into different function menus.

OSD Menus



• Color Temperature

sRGB



Night Vision

Brightness

The following settings will be grayed out when HDR signals are received:

- MPRT SyncLow Blue LightOptix ScopePIP/PBP
- HDCR Al Vision
- Contrast Display P3

G.I.

1st Level Menu	2nd/3rd Level Menu		Description	
Smart Crosshair	Icon	None [+]	Through AI algorithm the visibility of in-gan Users can select the c crosshair.	ne crosshair.
	Color	White Red Auto		
	Position			
	Reset			
Optix Scope	Scope Size	Small Medium	is enabled, user can a	zoom in when Optix Scope djust the details through "Scope Ratio" settings.
		Large	Smart Crosshair and 0	Optix Scope can be enabled
	Scope Ratio	x1.5	at the same time.Activating Optix Scop	e will affect:
		x2	Affected Function	Function Status
		х4	» MPRT Sync	
	OFF		» Adaptive-Sync	Set to OFF
	ON		» PIP/PBP » Screen Size 1:1	Set to Auto
MSI Dual Mode	OFF ON		MSI Dual Mode suppo 2160p at up to 160Hz Activating MSI Dual M	and 1080p at up to 320Hz.
			Affected Function	Function Status
			» PIP/PBP » DSC	Set to OFF & unable to select
			» Screen Size 16:10	Set to Auto & unable to select

Gaming

1st Level Menu	2nd/3rd Level Menu	Description
Game Mode Night Vision	User FPS Racing RTS RPG OFF Normal	Use Up or Down Button to select and preview mode effects. Press the OK Button to confirm and apply your mode type. Game Mode defaults to User in both SDR and HDR modes. This function optimizes background brightness and is recommended for FPS games.
	Strong Strongest A.I.	
Al Vision	OFF	Al Vision enhances image quality by optimizing the contrast of images and background brightness. Activating Al Vision will affect:
		Affected Function Function Status
		» MPRT Sync Set to OFF » HDCR » Brightness Unable to select » Night Vision
Response Time	Normal Fast Fastest	Setting to Fastest will reach the shortest response time and help improve blurred images when playing very fast games.
MPRT Sync	OFF ON	MPRT Sync is available when the refresh rate is over 85Hz. Activating MPRT Sync will affect:
		Affected Function Function Status
		Response Time Brightness HDCR PIP/PBP Optix Scope Al Vision Unable to select Set to OFF
		» Screen Size 1:1/ 24.5"/27" Set to Auto

1st Level Menu	2nd/3rd Level Menu		Description	
Refresh Rate	Location	Left Top	Location is adjustable	
		Right Top	OK Button to confirm Rate Location.	and apply your Refresh
		Left Bottom		and works at the Operating
		Right Bottom	System's preset Scree	en Refresh Rate.
		Customize		
	OFF			
	ON			
Alarm Clock	Location	Left Top	After setting the time,	press the OK Button to
		Right Top	activate the timer.Users have to manual	ly restore their preset
		Left Bottom	Alarm Clock after any	
		Right Bottom	reconnection.	
		Customize		
	OFF			
	15:00	00:01 ~ 99:59		
	30:00			
	45:00			
	60:00			
Adaptive-Sync	OFF	,	Adaptive-Sync preven	ts screen tearing.
	ON		with Adaptive-Sync (C when Screen Size 16:1	
			Activating Adaptive-Sylvania	ync will affect:
			Affected Function	Function Status
			» PIP/PBP » Optix Scope	Set to OFF
			» Screen Size 1:1/ 24.5"/ 27"	Set to Auto
DSC	OFF		Users can toggle DSC Compression) on/off.	(Display Stream
	ON		Preset Display Modes tables.	nformation, please check for DSC On/Off timing
			Activating DSC will aff Affected Function	
			» Screen Size 16:10 » PIP/PBP	Unable to select

Professional

1st Level Menu	2nd Level Menu	Description		
Pro Mode	User		on to select and preview mode	
	Anti-Blue	effects. • Press the OK Button to	o confirm and apply your mode	
	Movie	type.		
	Office	 Pro Mode defaults to I HDR mode. 	Eco for SDR mode and User for	
	sRGB			
	Display P3			
Low Blue Light	OFF		ts your eyes against blue light.	
	ON	When enabled, Low B temperature to a more	lue Light adjusts the screen color e yellow glow.	
		When Pro Mode is set enable Low Blue Light	to Anti-Blue, it is mandatory to t.	
HDCR	OFF		e quality by increasing the	
	ON	contrast of images. • Activating HDCR will affect:		
		Affected Function	Function Status	
		» MPRT Sync	Set to OFF	
		» Brightness	Unable to select	
MPRT Sync	OFF	MPRT Sync is available when the refresh rate is of		
	ON	85Hz. Activating MPRT Sync	will affect:	
		Affected Function	Function Status	
		» Response Time» Brightness	Unable to select	
		» HDCR » PIP/PBP » Optix Scope » Al Vision	Set to OFF	
		» Screen Size 1:1/ 24.5"/27"	Set to Auto	
Image Enhancement	OFF	Image Enhancement enhances image edges to it		
	Weak	their acutance.		
	Medium			
	Strong			
	Strongest			

Image

1st Level Menu	2nd/3rd Level Menu		Description	
Brightness	0-100		Properly adjust Brigh surrounding lighting.	
Contrast	0-100		Properly adjust Cont	rast to relax your eyes.
Sharpness	0-5		• Sharpness improves images.	clarity and details of
Color Temperature	Cool			on to select and preview
	Normal		mode effects. • Press the OK Button to	to confirm and apply your
	Warm		mode type.	to commin and apply your
	Customization	R (0-100)	 Users can adjust Colo Customization mode 	
		G (0-100)		
		B (0-100)		
Screen Size	Auto		Users can adjust Screen Size in any mode, any	
	4:3		resolution and any so	e 1:1/ 24.5" / 27" will affect:
	16:9		Affected Function	Function Status
	16:10		» MPRT Sync	T directori status
	1:1		» Adaptive-Sync	Set to OFF
	24.5"		» PIP/PBP	Set to orr
	27"		» Optix Scope	
			Important	
			at its original resolut	to displaying content ion. This option is onitor is set to its native

Input Source

1st Level Menu	2nd Level Menu	Description
HDMI™ 1		Users can adjust Input Source in any mode.
HDMI™ 2		
DP		
Auto Scan	OFF	Users can use the Navi Key to select Input Source at
	ON	 below status: While "Auto Scan" is set to "OFF" with the monitor at power saving mode;
		While "No Signal" message box is shown on the monitor.

PIP/PBP

1st Level Menu	2nd/3rd Level Menu		Description	
OFF		PIP (Picture in Picture) allows users to		
PIP	Source	simultaneously display mul HDMI™1 on one screen. One progran		
		HDMI™2		ame time as one or more splayed in inset windows.
		DP	PBP (Picture by Picture)	e) is a similar feature that
	PIP Size	Small	displays two input sou screen.	urces side-by-side on the
		Medium		users to switch between
		Large	primary and secondarIf there is only one sig	, ,
	Location	Left Top	Switch and Audio Swi	
		Right Top • Activating PIP/PBP will affect:	l affect:	
		Left Bottom	Affected Function	Function Status
		Right Bottom	» Response Time » DSC	Unable to select
		Customize	» MPRT Sync	
	Display Swit	ch	» Adaptive-Sync	Set to OFF
	Audio Switch		» Optix Scope » HDMI™ CEC	
PBP	Customize		» MSI Dual Mode	Set to OFF & unable to select
	Source 1	HDMI™1	» Screen Size 16:10	
		HDMI™2	» PIP: Screen Size 1:1/ 24.5" / 27"	Set to Auto & unable to select
		DP	» PBP: Screen Size	
	Source 2	HDMI™1		
		HDMI™2]	
		DP]	
	Display Switch		1	
	Audio Switch	1		

Navi Key

1st Level Menu	2nd Level Menu	Description
Up	OFF	All Navi Key items can be adjusted via OSD Menus.
Down	Brightness	
Left Right	Game Mode	
	Smart Crosshair	
	Alarm Clock	
	Input Source	
	PIP/PBP Mode	
	Refresh Rate	
	Info. On Screen	
	Night Vision	
	Optix Scope	
	MSI Dual Mode	

Settings

1st Level Menu	2nd Level Menu	Description
Language	繁體中文	Users have to press the OK Button to confirm and apply
	English	the Language setting. • Language is an independent setting. Users' own
	Français	language setting will override the factory default. When
	Deutsch	users set Reset to Yes, Language will not be changed.
	Italiano	
	Español	
	한국어	
	日本語	
	Русский	
	Português	
	简体中文	
	Bahasa Indonesia	
	Türkçe	
	(More languages coming soon)	
Transparency	0~5	Users can adjust Transparency in any mode.
OSD Time Out	5~30s	Users can adjust OSD Time Out in any mode.

1st Level Menu	2nd Level Menu	Description
RGB LED	OFF	Users can adjust RGB LED to ON or OFF.
	ON	
Power Button	OFF	When set to OFF, users can press the power button to turn off the monitor.
	Standby	When set to Standby, users can press the power button to turn off the panel and backlight.
Info. On Screen	OFF	The information of the monitor status will be shown on
	ON	the right side of the screen.
Eco Friendly	ON	This function adjusts the monitor backlight to improve
	OFF	energy efficiency.
HDMI™ CEC	OFF	HDMI TM CEC (Consumer Electronics Control) supports Consumer Section Section Consumer Section Consumer Section Consumer Section
	ON	Sony PlayStation®, Nintendo® Switch™, Xbox Series X S consoles and various audio-visual devices that are CEC-capable.
		If HDMI™ CEC is set to ON:
		The monitor will automatically power on when the CEC device is turned on.
		The CEC device will enter power saving mode when the monitor is turned off.
		 When Sony PlayStation®, Nintendo® Switch™, or Xbox Series X S console is connected, Game Mode and Pro Mode will be automatically set to default mode and can be adjusted to users' preferred modes later.
Power LED	OFF	Users can toggle the Power LED on/off.
	ON	-
Reset	YES	Users can Reset and restore settings to original OSD
	NO	Default in any mode.

Specifications

Monitor	MAG 322URDF E16
Size	32 inch
Curvature	Flat
Panel Type	Rapid IPS
Resolution	3840x2160 (UHD)
Aspect Ratio	16:9
Brightness	Typical SDR: 400 nits
	Peak HDR: 400 nits
Contrast Ratio	1000:1
Refresh Rate	Normal (UHD): 160Hz
	Dual (FHD): 320Hz
Response Time	• 1ms (MPRT)
	• 0.5ms (GtG)
I/O	2 x HDMI™ Connector
	• 1 x DisplayPort
	• 2 x USB 2.0 Type-A Port
	• 1 x USB 2.0 Type-B Upstream Port
	1 x Headphone Jack
View Angles	178°(H), 178°(V)
DCI-P3*/ sRGB	99%/ 131%
Surface Treatment	Anti-glare
Display Colors	1.07B, 10bits (8bits + FRC)
Monitor Power Options	100~240Vac, 50/60Hz, 1.5A
Power Consumption (Typical)	Power On < 100W
	Standby < 0.5W
	Power Off < 0.3W
Adjustment (Height)	0 ~ 110mm
Adjustment (Tilt)	-5° ~ 15°
Adjustment (Swivel)	-30° ~ 30°
Adjustment (Pivot)	-10° ~ 10°
Kensington Lock	Yes

Monitor		MAG 322URDF E16	
VESA Mounting	3	Plate Type: 100 x 100 mm	
		Screw Type: M4 x 10 mm	
Dimension (W x l	H x D)	714.08 x 564.48 x 227.76 mm	
Weight Gross		9 kg	
		13 kg	
Operating Envi	ironment	Temperature: 0°C to 40°C	
		Humidity: 20% to 90%, non-condensing	
		• Altitude: 0 ~ 5000m	
Storage Environment		• Temperature: -20°C to 60°C	
		• Humidity: 10% to 90%, non-condensing	

^{*} Based on CIE1976 test standards.

Preset Display Modes

Important

- All information is subject to change without prior notice.
- HDMI™ VRR (Variable Refresh Rate) synchronizes with Adaptive-Sync (ON/ OFF). For VRR ON/OFF status, please check Adaptive-Sync.
- To activate DSC-specific timing and frequency, ensure your graphics card supports DSC (Display Stream Compression).

Standard Mode (DSC On)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080	@60Hz	V	V	
QHD	2560x1440	@60Hz	V	V	
		@120Hz	V	V	
UHD	3840x2160	@60Hz	V	V	
		@144Hz	V	V	
		@160Hz	V	V	
Video Timing	720P		V	V	
Resolution	720P@120Hz		V	V	
	1080P	@60Hz	V	V	
		@120Hz	V	٧	
	2160P	@60Hz	V	V	
		@120Hz	V	V	
HDMI™ VRR			V		

Standard Mode (DSC Off)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080	@60Hz	V	V	
QHD	2560x1440	@60Hz	V	٧	
		@120Hz	V	٧	
UHD	3840x2160	@60Hz	V	V	
		@120Hz	V	٧	
		@144Hz	V		
		@160Hz	V		

Standard Mode (DSC Off)						
Standard	Resolution		HDMI™	DP		
Video Timing	720P		٧	V		
Resolution	720P	@120Hz	V	٧		
	1080P	@60Hz	V	٧		
		@120Hz	V	٧		
	2160P	@60Hz	V	V		
		@120Hz	V	V		
HDMI™ VRR			V			

Dual Mode (Enabled at Resolutions Other Than 4K)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080	@60Hz		V	
		@85Hz	V	V	
		@120Hz		V	
		@165Hz	V	V	
		@240Hz	V	V	
		@320Hz	V	V	
Video Timing	720P		V	V	
Resolution	1080P	@60Hz	V	V	
		@120Hz	V		
HDMI™ VRR			V		

Dual Mode (Enabled at 4K@60Hz)						
Standard	Resolution		HDMI™	DP		
Full HD	1920x1080	@120Hz	V	V		
Video Timing Resolution	1080P	@120Hz	V	V		
HDMI™ VRR			V			

Dual Mode (Enabled at 4K@120Hz)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080	1920x1080 @240Hz		٧	
HDMI™ VRR			V		

Dual Mode (Enabled at 4K@160Hz)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080 @320Hz		V	V	
HDMI™ VRR			V		

PIP Mode (Not Support HDR)					
Standard	Resolution		HDMI™	DP	
Full HD	1920x1080	@60Hz	V	V	
QHD	2560x1440	@60Hz	V	V	
		@120Hz	V	V	
UHD	3840x2160	@60Hz	V	V	
Video Timing	720P	720P		V	
Resolution	1080P	@60Hz	V	V	
	2160P	@60Hz	V	V	

PBP Mode (Not Support HDR)						
Standard	Resolution		HDMI™	DP		
Video Timing Resolution	720P		V	V		
Used for PBP Full Screen	1920x2160	@60Hz	V	V		

Screen Size 16:10 (Not Support HDR)				
Standard	Resolution		HDMI™	DP
QHD+	2560x1600	@60Hz	V	V
		@120Hz	V	V
		@144Hz	V	V

Troubleshooting

The power LED is off.

- Press the monitor power button again.
- Check if the monitor power cable is properly connected.

No image.

- Check if the computer graphics card is properly installed.
- Check if the computer and monitor are connected to electrical outlets and are turned on.
- Check if the monitor signal cable is properly connected.
- The computer may be in Standby mode. Press any key to activate the monitor.

The screen image is not properly sized or centered.

 Refer to Preset Display Modes to set the computer to a setting suitable for the monitor to display.

No Plug & Play.

- Check if the monitor power cable is properly connected.
- Check if the monitor signal cable is properly connected.
- Check if the computer and graphics card are Plug & Play compatible.

The icons, font or screen are fuzzy, blurry or have color problems.

- Avoid using any video extension cables.
- · Adjust brightness and contrast.
- Adjust RGB color or tune color temperature.
- Check if the monitor signal cable is properly connected.
- Check for bent pins on the signal cable connector.

The monitor starts flickering or shows waves.

- Change the refresh rate to match the capabilities of your monitor.
- Update your graphics card drivers.
- Keep the monitor away from electrical devices that may cause electromagnetic interference (EMI).

Safety Instructions

- Read the safety instructions carefully and thoroughly.
- All cautions and warnings on the device or User Guide should be noted.
- Refer servicing to qualified personnel only.

Power

- Make sure that the power voltage is within its safety range and has been adjusted properly to the value of 100~240V before connecting the device to the power outlet.
- If the power cord comes with a 3-pin plug, do not disable the protective earth pin from the plug. The device must be connected to an earthed mains socket-outlet.
- Please confirm the power distribution system in the installation site shall provide the circuit breaker rated 120/240V, 20A (maximum).
- Always disconnect the power cord or switch the wall socket off if the device would be left unused for a certain time to achieve zero energy consumption.
- Place the power cord in a way that people are unlikely to step on it. Do not place anything on the power cord.
- If this device comes with an adapter, use only the MSI provided AC adapter approved for use with this device.

Environment

- To reduce the possibility of heat-related injuries or of overheating the device, do not place the device on a soft, unsteady surface or obstruct its air ventilators.
- Use this device only on a hard, flat and steady surface.
- To prevent the device from tipping over, secure the device to a desk, wall or fixed object with an anti-tip fastener that helps to properly support the device and keep it safe in place.
- To prevent fire or shock hazard, keep this device away from humidity and high temperature.
- Do not leave the device in an unconditioned environment with a storage temperature above 60°C or below -20°C, which may damage the device.
- The maximum operating temperature is around 40°C.
- When cleaning the device, be sure to remove the power plug. Use a piece of soft cloth rather than industrial chemical to clean the device. Never pour any liquid into the opening; that could damage the device or cause electric shock.
- Always keep strong magnetic or electrical objects away from the device.

- If any of the following situations arises, get the device checked by service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the device.
 - The device has been exposed to moisture.
 - The device does not work well or you can not get it working according to the User Guide.
 - The device has dropped and damaged.
 - The device has obvious sign of breakage.

TÜV Rheinland Certification

TÜV Rheinland Low Blue Light Certification

Blue light has been shown to cause eye fatigue and discomfort. MSI now offers monitors with TÜV Rheinland Low Blue Light certification to ensure users' eye comfort and well-being. Please follow the instructions below to reduce the symptoms from extended exposure to the screen and blue light.



- Place the screen 20 28 inches (50 70 cm) away from your eyes and a little below eye level.
- Consciously blinking the eyes every now and then will help to reduce eye strain after extended screen time.
- Take breaks for 20 minutes every 2 hours.
- Look away from the screen and gaze at a distant object for at least 20 seconds during breaks.
- Make stretches to relieve body fatigue or pain during breaks.
- Turn on the optional Low Blue Light function.

TÜV Rheinland Flicker Free Certification

 TÜV Rheinland has tested this product to ascertain whether the display produces visible and invisible flicker for the human eye and therefore strains the eyes of users.



- TÜV Rheinland has defined a catalogue of tests, which sets out minimum standards at various frequency ranges. The test catalogue is based on internationally applicable standards or standards common within the industry and exceeds these requirements.
- The product has been tested in the laboratory according to these criteria.
- The keyword "Flicker Free" confirms that the device has no visible and invisible flicker defined in this standard within the range of 0 - 3000 Hz under various brightness settings.
- The display will not support Flicker Free when Anti Motion Blur/MPRT is enabled. (The availability of Anti Motion Blur/MPRT varies by products.)

Regulatory Notices

CE Conformity

This product has been tested and found to comply with the harmonized standards for Information Technology Equipment published under Directives of Official Journal of the European Union.



FCC-B Radio Frequency Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may



cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the measures listed below:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/television technician for help.

Notice 1

The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notice 2

Shielded interface cables and AC power cord, if any, must be used in order to comply with the emission limits

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

MSI Computer Corp.

901 Canada Court, City of Industry, CA 91748, USA (626) 913-0828

www.msi.com

WEEE Statement

Under the European Union ("EU") Directive on Waste Electrical and Electronic Equipment, Directive 2012/19/EU, products of "electrical and electronic equipment" cannot be discarded as municipal waste anymore and manufacturers of covered electronic equipment will be obligated to take back such products at the end of their useful life.



Chemical Substances Information

In compliance with chemical substances regulations, such as the EU REACH Regulation (Regulation EC No. 1907/2006 of the European Parliament and the Council), MSI provides the information of chemical substances in products at: https://csr.msi.com/global/index

RoHS Statement

Japan JIS C 0950 Material Declaration

A Japanese regulatory requirement, defined by specification JIS C 0950, mandates that manufacturers provide material declarations for certain categories of electronic products offered for sale after July 1, 2006.

https://csr.msi.com/global/Japan-JIS-C-0950-Material-Declarations

India RoHS

This product complies with the "India E-waste (Management and Handling) Rule 2016" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 weight % and 0.01 weight % for cadmium, except for the exemptions set in Schedule 2 of the Rule.

Turkey EEE Regulation

Conforms to the EEE Regulations of the Republic Of Turkey

Ukraine Restriction of Hazardous Substances

The equipment complies with requirements of the Technical Regulation, approved by the Resolution of Cabinet of Ministry of Ukraine as of 10 March 2017, № 139, in terms of restrictions for the use of certain dangerous substances in electrical and electronic equipment.

Vietnam RoHS

As from December 1, 2012, all products manufactured by MSI comply with Circular 30/2011/TT-BCT temporarily regulating the permitted limits for a number of hazardous substances in electronic and electric products.

Green Product Features

- Reduced energy consumption during use and stand-by
- Limited use of substances harmful to the environment and health
- Easily dismantled and recycled
- Reduced use of natural resources by encouraging recycling
- Extended product lifetime through easy upgrades
- Reduced solid waste production through take-back policy

Environmental Policy

- The product has been designed to enable proper reuse of parts and recycling and should not be thrown away at its end of life.
- Users should contact the local authorized point of collection for recycling and disposing of their end-of-life products.



- Visit the MSI website and locate a nearby distributor for further recycling information.
- Users may also reach us at gpcontdev@msi.com for information regarding proper disposal, take-back, recycling, and disassembly of MSI products.
- Please visit <https://us.msi.com/page/recycling for information regarding the recycling of your product in the US.

Warning!

Overuse of screens is likely to affect eyesight.

Recommendations:

- 1. Take a 10-minute break for every 30 minutes of screen time.
- 2. Children under 2 years of age should have no screen time. For children aged 2 years and over, screen time should be limited to less than one hour per day.

Copyright and Trademarks Notice

mSi MSI 微星





Copyright © Micro-Star Int' I Co., Ltd. All rights reserved. The MSI logo used is a registered trademark of Micro-Star Int' I Co., Ltd. All other marks and names mentioned may be trademarks of their respective owners. No warranty as to accuracy or completeness is expressed or implied. MSI reserves the right to make changes to this document without prior notice.



The terms HDMI[™], HDMI[™] High-Definition Multimedia Interface, HDMI[™] Trade dress and the HDMI[™] Logos are trademarks or registered trademarks of HDMI[™] Licensing Administrator, Inc.

Technical Support

If a problem arises with your product and no solution can be obtained from the user's manual, please contact your place of purchase or local distributor. Alternatively, please visit https://www.msi.com/support/ for further guidance.